

# Temporary Seeding

## *The Good.....*



Sites that will be inactive for more than 14 days must be temporarily stabilized by the 7<sup>th</sup> day.

## *The Bad.....*



Site that have been temporarily seeded must continue to be inspected and the BMP's maintained to assure there are no failures

Timing of seeding is also critical. This areas was Seeded and hydro-mulched in December which means the hydro-mulch will fail before there is adequate vegetation.

## *And The Ugly.....*



Idle areas that were not temporarily seeded in the required timeframe.

Weeds are not considered temporary cover. A record of the seed mix should be kept in the SWPPP